MITSUBISHI ASSERTION FIGHTER



Pack 10 | Build Instructions

Your 1:18 model of the Japanese Zero is reproduced in the most exquisite detail, with electronics allowing you to recreate aeronautical operations such as take-off and landing, turning, firing and night combat. Lights, machine-gun and propeller sounds bring your legendary fighter plane to life.

In your tenth model pack, you will assemble:

STAGE 78: INSTALLING THE RIGHT FRONT AND REAR EXTERNAL PANELS

STAGE 79: INSTALLING THE LIFTING DEVICE FOR THE DISPLAY PEDESTAL (2)

STAGE 80: ASSEMBLING THE RIGHT HORIZONTAL TAIL WING AND DISPLAY PEDESTAL STAGE 81: ASSEMBLING THE DROP TANK AND DISPLAY PEDESTAL

STAGE 82: ASSEMBLING THE GEARBOX FOR THE DISPLAY PEDESTAL LIFTING DEVICE (2)

STAGE 83: ASSEMBLING THE LIMIT SWITCH

STAGE 84: ASSEMBLING THE DISPLAY PEDESTAL









Advice from the experts

Spare screws are included with each part. Occasionally, you may be instructed to keep spare or unused screws for a later stage. Keep these spares in a safe place and label them correctly.

Please make sure you don't mix up the screws. They look quite similar, but the threads do vary slightly. Using the wrong screws may damage the parts.

When securing parts together using multiple screws, fit each screw loosely to ensure all the parts are correctly aligned before gently tightening them firmly, but not overtight, in the order in which you placed them.

The screwdriver can be magnetised by stroking it with a magnet (fridge magnet, etc.) enabling it to hold the screws and make assembly easier.

If a screw is tight going into a metal part, do not force it as you may shear the head off. Remove it and put a tiny smear of Vaseline, soap or light oil on the thread. That will lubricate it and make it easier to drive home.

During the course of this build, you will receive many pieces that you will assemble immediately – following the instructions in the corresponding stage – and other pieces that you should store safely to one side, for use in future assembly stages.

When gluing parts together, glue may be applied to either of the two parts. Some experts find it asier to apply glue to a hole rather than a pin. Choose a method that works best for you.

It's a good idea to test fit your parts so that you can check their positioning before gluing.

Not suitable for children under the age of 14. This product is not a toy and is not designed for use in play. Keep the parts out of the reach of small children. Some parts may have sharp edges. Please handle them with care.



Stage 78: Installing the Right Front and Rear External Panels



Stage 78 Assembly

External Panels


In this stage we'll be assembling the front and rear external panels for the right side of the aircraft and then attaching them to the main frame.


STAGE 78 PARTS **PARTS LIST** 078-01 Die-cast 078-01 078-02 Steel (1 spare) 078-03 Steel (1 spare 078-04 Steel (1 spare You will also need: screwdriver *Parts may differ from those shown but this will not affect assembly.




Installing the right front and rear external panels









Fit the right front panel 077-01 that came with Stage 77 onto the right rear panel 078-01, and fix them together with 2 x screws 078-02.






Fit the right external panel assembled in 1 from the right side of the fuselage. Insert the horizontal stabilizer into the hole in the right rear panel 078-01 first, and then push the entire external panel forwards to make it easier to fit.




Fix the right front panel 077-01 with the screw 077-03 that came with Stage 77.




Fix one part of the left rear panel 075-01 with 1 x screw 078-03 and fix the right rear panel 078-01 with 2 x screws 078-04.








Fit the vertical stabiliser 075-03 that came with Stage 75 into place as shown.






Insert the fairing (left) 074-04 that came with Stage 74 onto the elevator (left). Insert the fairing (right) 077-02 that came with Stage 77 onto the elevator (right). Insert the fairing all the way to the base and then push it forward so that it fits into the recess in the rear external panel.





Stage 79: Installing the Lifting Device for the Display




Stage 79 Assembly

Lifting Device

In this stage we'll be assembling the lifting device to be fitted inside the display, which is a vital component when it comes to making the A6M Zero "fly". Pay extra attention when connecting limit switches up to their corresponding parts.

STAGE 79 PARTS



You will also need: screwdriver

- * 079-06, 079-07, & 079-09 will not be used in this stage. Keep in a safe place until required.
- * Parts may differ from those shown but this will not affect assembly.


PARTS LIST


Part	No.	Material
079-01	1	РОМ
079-02	2	Steel
079-03	1	ABS resin
079-04	1	Acrylic
079-05	1	MDF
079-06	1	Steel
079-07	1	Steel
079-08	8 (1 spare)	Steel
079-09	6	Steel




Assembling the lifting device








Insert the slider 079-01 onto the lifting device base 071-05 that came with Stage 71. Insert two shafts 079-02 through the slider into the lifting device base.






Insert the lifting device frame 079-03 from above the two shafts 079-02.





Insert the support bar 079-04 through the hole at the top of the lifting device frame 079-03 into the slider 079-01.




Fix the lifting device frame 079-03 in places with 6 x screws 079-08.









Slide the limit switch frame 069-02 assembled in Stage 69 into the groove on the lifting device frame 079-03 and fit it.






Fix the limit switch frame 069-02 with 1 x screw 079-08.


Assembling the display pedestal







Fit the grooves on the pedestal frame 079-05 into the pedestal plates 072-03 and 069-04 of the pedestal assembled in Stage 72.









Align the metal fitting 071-02 that came with Stage 71 with the pedestal frames 069-04 and 079-05.





Fix the metal fitting in place with 4 x screws 071-07 that came with Stage 71.





Stage 80: Assembling the Right Horizontal Tail Wing and Display Pedestal



Stage 80 Assembly

Horizontal Wing Tail

In this stage we'll install the outer panels for the horizontal tail wing located on the right side of the aircraft, as well as install the speaker in the display pedestal.

STAGE 80 PARTS

080-01

PARTS LIST

Part	No.	Material
080-01	1	Die-cast
080-02	1	ABS resin
080-03	1	Bomb


You will also need: superglue, screwdriver


- * Part 080-03 will not be used in htis stage. Keep in a safe place until required.
- * Parts may differ from those shown but this will not affect assembly.



Assembling the right horizontal tail wing








Apply superglue to the 5 pins on the underside of the right horizontal tail wing 080-02 and glue it to the underside of the right tail wing frame, then attach the right horizontal tail wing (topside) 080-01 from above.

STEP 2

Assembling the display pedestal



Insert the speaker 076-01 from Stage 76 into the pedestal assembled in Stage 79, and fix it with the two screws 076-05 that also came in Stage 76





Stage 81: Assembling the Drop Tank and Display Pedestal



As the A6M Zero was well-known for its capacity to range quite a way from its home carrier it required an extra fuel tank, which we'll be assembling in this stage, as well as continuing work on the display pedestal. Make sure you fit the drop tank parts together, leaving no gaps or space between them.

Stage 81 Assembly

Drop Tank / Pedestal

STAGE 81 PARTS Part No. 081-01 1 A 081-02 1 A 081-03 1 A 081-04 1 You will also need: screwdriver Parts may differ from those shown but this will not affect assembly.

ABS resin

ABS resin

ABS resin

MDF




Assembling the drop tank








Fit the two drop tank parts 081-01 and 081-02 together.






Align the thinner and fatter protrusions on the drop tank with the drop tank head 081-03.



STEP 2 Assembling the display pedestal



Align the pedestal plates 073-02 and 081-04 with the pedestal assembled in Stage 80, and the metal fitting 076-04 from Stage 76. Fix in place using 4 x screws 076-05.





Stage 82: Assembling the Gearbox for the Display Pedestal Lifting Device (2)



Stage 82 Assembly


Lifting Device Gearbox In this stage we'll assemble the gearbox which is integral to the operation of the lifting device fitted in the display pedestal. We'll be working with four different gears during this stage so pay extra attention to the order you should place them in as well as the direction they should be facing.


STAGE 82 PARTS PARTS LIST 082-01 082-02 082-04 082-01 ABS resin 082-03 082-02 ABS resin 082-03 Steel 082-04 Motor 082-05 Steel+Plastic 082-07 082-08 П 082-06 Plastic 082-07 Plastic You will also need: screwdriver * Parts may differ from those shown but this will not affect assembly. П 082-08 Plastic



Assembling the gearbox for the display pedestal lifting device










Insert three shafts 082-03 into the gearbox 082-01. Push firmly as the holes are quite narrow.






Feed the wire from motor 082-04 through the hole in gearbox 082-01 and fit the motor with the wire facing down.







Insert the longer shaft of the camshaft 082-05 from under the gearbox 082-01.








Insert gear 082-08 and 2 x gears 082-07 onto the three shafts 082-03 inserted in 1, in order, starting from the side closest to the motor. Make sure that the small gear faces upward. Finally, fit the gear 082-06 onto the camshaft 082-05 inserted in step 3 with the small gear facing down.



Cover the gearbox 082-01 with the gearbox lid 082-02 and fit the claws.



Applying a small amount of grease or lubricant to the gears will help to make them run more smoothly.





Stage 83: Assembling the Limit Switch



Stage 83 Assembly

Limit Switch

In this stage we'll be assembling a limit switch. As always, when attaching the switch to the frame make sure this is securely fastened and doesn't slip around.

STAGE 83 PARTS



You will also need: screwdriver

- * Parts **083-02**, **083-04** & **083-07** will not be used in this stage. Keep them in a safe place until required.
- * Parts may differ from those shown but this will not affect assembly.


PARTS LIST

Part	No.	Material
083-01	1	ABS resin
083-02	1	ABS resin
083-03	1	Limit switch
083-04	1	ABS resin
083-05	1	ABS resin
083-06	2	Steel
083-07	2 (1 spare)	Steel
083-08	5 (1 spare)	Steel




Assembling the limit switch








Fit the limit switch 083-03 into the frame 083-01, aligning the cut corners of the board of the limit switch 083-03 with the triangular protrusions on the frame 083-01.





Fix the limit switch in place with 4 x 083-08 screws. Note that there is a little room to move the screw holes left and right. Check that the cut corner of the limit switch is aligned with the triangular protrusion on the board before tighteneing the screws to ensure correct alignment.





Stage 84: Assembling the Display Pedestal



Stage 84 Assembly

Pedestal


In this stage we'll be working on the pedestal again. When screwing in the metal fittings to the base plates or outer frames hold these fast so they don't slip around.

STAGE 84 PARTS **PARTS LIST** 084-01 084-01 084-02 Steel 084-02 084-03 Steel 084-04 084-04 Adapter 084-05 084-03 084-06 084-05 Steel You will also need: screwdriver * Parts 084-04 & 084-06 will not be used in this stage. Keep them safe until required. 084-06 Steel * Parts may differ from those shown but that will not affect assembly.





Assembling the display pedestal







Fit the groove on the outer frame 084-01 into the pedestal plate 073-03 assembled in Stage 81.





Align the metal fitting 084-02 with the pedestal frame parts 079-05 and 084-01, and fix in place with 4 x screws 084-05.





Align the metal fitting 084-03 with the pedestal frame parts 079-05 and 084-01, and fix them in place with 2×100 screws 084-05.

